

SNAP Heavy Duty Pavement Sign: Assembly Instructions



What you should have in your product, please check you have all the items before assembling.



Attach springs to base: insert the wing screw and washer to the underneath of the base and fasten by screwing the spring to the top of the base (see images 2 and 3).



Repeat.



Attach frame to springs and base: align the poster frame to the springs and attach them by tightening together with the smaller bolts and spanner.



Finished view.